



Windows Driver Installer Manual

1.Please connect the USB flash drive to your computer.


2.Double click to open (RacerDisplayDriver-2024.9.13-en.exe) to install the driver.




3.Click “Next” to proceed to the next step.




4. Click “I Agree” to proceed to the next step.



5. Click “Install” to proceed to the next step.




6. Wait for the installation, after the installation is complete, there will be a pop-up box “Please reboot”, click OK.



7. When the installation is complete, click “Finish” and restart your computer.


USB screen can be accessed after the computer reboot is completed.




Q&A

How do I uninstall an installed USB driver?


1. Click the Win key on your keyboard and search for “Control panel” to open the control panel.




2. Open “Programs and Features”.



3. Double-click to uninstall RacerDisplayDriver-2024.9.12 driver



3.A pop-up box will appear asking if you want to uninstall the USB driver, click “Yes”.



4.Click “OK” to complete the uninstallation.

